


## ASSEMBLY WITH ONE INNER PACKAGING



### ASSEMBLY DETAILS:

## FIBREBOARD BOX: 4G OUTER

**CODE:1**  
**CODE 44**

(WITH FLAMMABLE  
HAZARD LABEL)

**GB/0582**

FOR PACKING GROUPS:

I II III  
X Y Z



4G/X11/S/\*\*  
GB/0582

\*\* Denotes year of manufacture

### External Dimensions:

180 x 180 x 310mm

### Internal Dimensions:

100 x 100 x 300mm

### NOTES:

Each **Fibreboard Box OUTER 4G** is U.N Certified to contain specific **INNERS** in specific conformations. The approved mode of packing **must be** strictly adhered to in order to comply with U.N. Regulations.


Vermiculite IS required as absorbent filling of the remaining available space.

Once closed, box **must be** sealed with 50mm adhesive tape in a 'U' shape.

## APPROVED INNERS (ONE INNER PER OUTER BOX)

Code	Volume (ml)	Material	Code	Volume (ml)	Material
891	625	Aluminium	79	2000	LDPE
5	1000	Aluminium	129 or 143	250	Glass Reagent (140 or 180C)
182	1250	Aluminium	130 or 144	500	Glass Reagent (140 or 180C)
87	300	LDPE	131 or 145	1000	Glass Reagent (140 or 180C)
9	500	LDPE	3	1000	Tinplate Lacquered
88	750	LDPE	51	1000	Tinplate Lacquered
8	1000	LDPE	54	2000	Tinplate Lacquered

## ASSEMBLY WITH MULTIPLE INNER PACKAGINGS



### ASSEMBLY DETAILS:

## FIBREBOARD BOX: 4G OUTER

**CODE:1**  
**CODE 44**

(WITH FLAMMABLE  
HAZARD LABEL)

**GB/0582**

### FOR PACKING GROUPS:

I II III  
X Y Z



4G/X11/S/\*\*  
GB/0582

\*\* Denotes year of manufacture

### External Dimensions:

180 x 180 x 310mm

### Internal Dimensions:

100 x 100 x 300mm

### NOTES:

Each Fibreboard Box OUTER 4G is U.N. Certified to contain specific INNERS in specific conformations. The approved mode of packing **must be** strictly adhered to in order to comply with U.N. Regulations.

(1) Assemble the box and tape at the base with 50mm adhesive tape in a "U" shape before adding the buffer partitions. Then add a small layer of vermiculite.

(2) Place the first inner into the box and add vermiculite to just above the level of the inner packaging.

(3) Add a layer pad, a small layer of vermiculite and repeat step 2.

(4) If packing 3 inners repeat step 3.

(5) If packing 4 inners repeat step 3.

(6) Fill all void spaces within the box and once closed, seal with 50mm adhesive tape in a 'U' shape.

## APPROVED INNERS (MULTIPLE INNERS PER OUTER BOX)

Code	Volume (ml)	Material	Quantity to pack	Layer Pads Required
83	200	LDPE	2	1
80	250	LDPE	2	1
569	250	Tinplate Lacquered	4	3
59	500	Tinplate Lacquered	2	1
533	500	Tinplate Lacquered	3	2